

Period: 2010-07-01 - 2010-07-06

| Date | Process | PP Code | Product Type | Brand | Fit Model | Replace Code | Others |
|----------|-------------|--------------|----------------|-----------|--|--------------|---|
| 2010/7/1 | Add | PL140B | Battery | CASIO | Exilim Hi-ZOOM EX-H5 | | Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACPMB140 |
| 2010/7/1 | Add | PL140B | Battery | NIKON | Coolpix S203 | | Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACPMB140 |
| 2010/7/1 | Add | PL178B | Battery | SANYO | Xacti DMX-CG100, Xacti DMX-CG110, Xacti DMX-CS1, Xacti DMX-GH1 | | Category: Camcorder Related Products: AVEP178, AVMP178, AVCP178, ACPMB178, AVNS178 |
| 2010/7/1 | Add | Original Tip | Connector Tips | FUJITSU | LifeBook AH550 | | Category: Laptop Related Products: AC090.008, AC120.009, AC150.010, DC120.003, DC091.006, AC090X.008, AC120X.009, AC150X.010, EL1691, EL1692 |
| 2010/7/1 | Add | C27 | Connector Tips | ACER | Aspire one series 532h-2Ds | | Category: Laptop Related Products: AC090.008C27, EL1901, EL1691, EL1692, EL1695, EL1696 |
| 2010/7/2 | Add | CL5123S | Battery | SONY | VPC-S115FG | | Category: Laptop |
| 2010/7/2 | Add | CL4238B | Battery | TOSHIBA | NB205-N230 | | Category: Laptop |
| 2010/7/2 | Add | CL4238S | Battery | TOSHIBA | NB205-N230 | | Category: Laptop |
| 2010/7/2 | Add | CL6146B | Battery | FUJITSU | FMV-S8490 | | Category: Laptop |
| 2010/7/3 | Delete | CL7695B | Battery | | | | Remark: In using this replacement battery, a warning message of "NOT ORIGINAL / GENUINE BATTERY" will appear whenever switching on your computer. Computer functioning and battery charging would not be affected. What you need to do is to shut down the notice by clicking the "Power Manager". |
| 2010/7/3 | Delete | CL7697B | Battery | | | | Remark: 1) In using this replacement battery, a warning message of "NOT ORIGINAL / GENUINE BATTERY" will appear whenever switching on your computer. Computer functioning and battery charging would not be affected. What you need to do is to shut down the notice by clicking the "Power Manager". |
| 2010/7/3 | Delete | CL7139B | Battery | | | | Remark: 1) In using this replacement battery, a warning message of "NOT ORIGINAL / GENUINE BATTERY" will appear whenever switching on your computer. Computer functioning and battery charging would not be affected. What you need to do is to shut down the notice by clicking the "Power Manager". |
| 2010/7/5 | Add | CL2860B | Battery | HP | EliteBook 8740w, ProBook 6545b | | Category: Laptop |
| 2010/7/5 | Add | CL2628B | Battery | ACER | Aspire 5596WXM | | Category: Laptop |
| 2010/7/5 | Add | CL8751E | Battery | PANASONIC | CF-T9JCFDCS, CF-T9JCFDDS, CF-T9JWFDCS, CF-T9JWFDDS | | Category: Laptop |
| 2010/7/5 | New Product | AVP813 | Charger Plate | | | | |

| | | | | | | | |
|----------|-------------|------------|-----------------|-------|--|--|------------------|
| 2010/7/5 | New Product | ACP813 | Charger Plate | | | | |
| 2010/7/5 | New Product | ACMPB813Z | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | ACMPB813L | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | ACMPB813E | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | ACMPB813A | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | ACMPB813H | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813LZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813A | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813K | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813AZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813EZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813KZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813L | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVCP813E | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SK | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SE | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SAZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SEZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813U | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813E | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813UZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813K | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813A | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813AZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813KZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813EZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SUZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SJ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SJZ | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SA | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813P | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SU | Battery Charger | CANON | | | |
| 2010/7/5 | New Product | AVMP813SKZ | Battery Charger | CANON | | | |
| 2010/7/5 | Add | C7 | Connector Tips | ACER | Aspire One 532h-2067, Aspire One 532h-2206, Aspire One 532h-2223, Aspire One 532h-2268, Aspire One 532h-2288, Aspire One 532h-2298, Aspire One 532h-2309, Aspire One 532h-2326, Aspire One 532h-2333, Aspire One 532h-2382, Aspire One 532h-2406, Aspire One 532h-2527, Aspire One 532h-2588, Aspire One 532h-2594, Aspire One 532h-2622, Aspire One 532h-2727, Aspire One 532h-2730, Aspire One 532h-2742, Aspire One 532h-2789, Aspire One 532h-2806, Aspire One 532h-2825, Aspire One 532h-2938, Aspire One 532h-2942, Aspire One 532h-2962, Aspire One 532h-2964, Aspire One 532h-2997, Aspire One 532h-2Bb, Aspire One 532h-2Bs, Aspire One 532h-2Db, Aspire One 532h-2Dr, Aspire | | Category: Laptop |

| | | | | | | | |
|----------|-------------|-------------|-----------------|---------|---|--|---|
| | | | | | One 532h-B123F, Aspire One 532h-CBW123G, Aspire One 532h-CPK11, Aspire One 532h-CPR11, Aspire One 532h-CPW11, | | Related Products: AC090.008C7, DC091.006C7, DC090.006C7, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696 |
| 2010/7/5 | New Product | AVP289 | Charger Plate | | | | |
| 2010/7/5 | New Product | AVMP289A | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289AZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289E | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289EZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289K | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289KZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SJ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SJZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289P | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SA | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SAZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SE | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SEZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SK | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SKZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SU | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289SUZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289U | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVMP289UZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289E | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289K | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289U | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289SA | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289SE | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289SK | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVNS289SU | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | ACP289 | Charger Plate | | | | |
| 2010/7/5 | New Product | ACMPB289A | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | ACMPB289E | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | ACMPB289H | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | ACMPB289L | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | ACMPB289Z | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289AZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289EZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289KZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289LZ | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289A | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289E | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289K | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | AVCP289L | Battery Charger | SAMSUNG | | | |
| 2010/7/5 | New Product | PL819B.725 | Battery | CANON | | | |
| 2010/7/5 | New Product | CL1012B.080 | Battery | ASUS | | | |
| 2010/7/5 | New Product | CL1012B.082 | Battery | ASUS | | | |
| 2010/7/5 | New Product | CL1012B.083 | Battery | ASUS | | | |
| 2010/7/5 | New Product | CL1012B.085 | Battery | ASUS | | | |
| 2010/7/5 | New Product | CL1012B.086 | Battery | ASUS | | | |

| | | | | | | | |
|----------|-------------|-------------|----------------|----------|------------------|-----------|--|
| 2010/7/5 | New Product | CL1012B.087 | Battery | ASUS | | | |
| 2010/7/5 | Add | M1 | Connector Tips | APPLE | iPhone 4G | | Category: Mobile Phone Related Products: CALM5015.007, EL509, EL1695, EL1696, EL3562, EL590 |
| 2010/7/5 | Add | P6 | Connector Tips | HTC | Google nexus one | | Category: PDA Related Products: CALM5015.007, EL509, EL1695, EL1696, EL3562, EL590 |
| 2010/7/5 | Add | M10 | Connector Tips | HTC | Desire | | Category: PDA Related Products: CALM5015.007, EL509, EL1695, EL1696, EL3562, EL590 |
| 2010/7/6 | Add | CL3147B | Battery | DELL | Inspiron 1570n | | Category: Laptop |
| 2010/7/6 | Add | CL3147B | Battery | DELL | | 451-11469 | Category: Laptop |
| 2010/7/6 | Amend | PL600D.142 | Battery | | | | Size: 45.10 x 31.90 x 33.70 mm -> 45.10 x 31.90 x 18.70 mm |
| 2010/7/6 | New Product | BL3001B.545 | Battery | MOTOROLA | | | |
| 2010/7/6 | New Product | BL0904B.545 | Battery | SAMSUNG | | | |