

**Period: 2010-07-07 - 2010-07-13**

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010/7/7	Amend	CL2516B.085	Battery				Color: Dark Grey -> Black
2010/7/7	Amend	PL152B.533	Battery				Status: Available -> Stop Production
2010/7/7	Amend	BL1672D.445	Battery				Status: Available -> Stop Production
2010/7/7	Amend	BL463B.043	Battery				Status: Available -> Stop Production
2010/7/7	Delete	CL1847B	Battery	COMPAQ	Presario CQ60 Series, Presario CQ61, Presario CQ70 Series		Category: Laptop
2010/7/7	Delete	CL1847B	Battery	HP	G60 Series, G70 Series		Category: Laptop
2010/7/7	Delete	CL1848B	Battery	COMPAQ	Presario CQ60 Series, Presario CQ61, Presario CQ70 Series		Category: Laptop
2010/7/7	Delete	CL1848B	Battery	HP	G60 Series, G70 Series		Category: Laptop
2010/7/7	Add	CL655B	Battery	FUJITSU	LifeBook TH700		Category: Laptop
2010/7/7	Add	C7	Connector Tips	ACER	Aspire One 532h-2Ds		Category: Laptop Related Products: AC090.008C7, DC091.006C7, DC090.006C7, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696
2010/7/8	Add	TB040G	Battery	BOSCH		2 607 335 465	Category: Power Tools
2010/7/8	Add	TB040R	Battery	BOSCH		2 607 335 465	Category: Power Tools
2010/7/8	Amend	PLW819D.725	Battery				Status: Available -> Stop Production

2010/7/8	Delete	CL1847B	Battery	COMPAQ	Presario CQ60-100 Series, Presario CQ60-200 Series, Presario CQ60-202TX, Presario CQ60-204TU, Presario CQ60-208TX, Presario CQ60-300 Series, Presario CQ60-400, Presario CQ60-400, Presario CQ60-419WM, Presario CQ61-100, Presario CQ61-100, Presario CQ61-200, Presario CQ61-200, Presario CQ61-300, Presario CQ61-300, Presario CQ70-100 Series, Presario CQ70-100ER, Presario CQ70-101TU, Presario CQ70-101TX, Presario CQ70-101XX, Presario CQ70-102TU, Presario CQ70-102TX, Presario CQ70-102XX, Presario CQ70-103EB, Presario CQ70-103EF, Presario CQ70-103EM, Presario CQ70-103TU, Presario CQ70-103TX, Presario CQ70-104TX, Presario CQ70-105EB, Presario CQ70-105EF, Presario CQ70-105TX, Presario CQ70-110EB, Presario CQ70-110EF, Presario CQ70-110EM, Presario CQ70-110EO, Presario CQ70-110ER, Presario CQ70-110ES, Presario CQ70-111CA, Presario CQ70-115EE, Presario CQ70-115EF, Presario CQ70-115EO, Presario CQ70-	Category: Laptop
2010/7/8	Delete	CL1847B	Battery	HP	G60-100 Series, G60-200, G60-200, G60-230US, G70-100 Series, G70-250us	Category: Laptop

2010/7/8	Delete	CL1848B	Battery	COMPAQ	Presario CQ60-100 Series, Presario CQ60-200, Presario CQ60-200, Presario CQ60-202TX, Presario CQ60-204TU, Presario CQ60-208TX, Presario CQ60-300, Presario CQ60-300, Presario CQ60-400, Presario CQ60-400, Presario CQ60-419WM, Presario CQ61-100, Presario CQ61-100, Presario CQ61-200, Presario CQ61-200, Presario CQ61-300, Presario CQ61-300, Presario CQ70-100 Series, Presario CQ70-100ER, Presario CQ70-101TU, Presario CQ70-101TX, Presario CQ70-101XX, Presario CQ70-102TU, Presario CQ70-102TX, Presario CQ70-102XX, Presario CQ70-103EB, Presario CQ70-103EF, Presario CQ70-103EM, Presario CQ70-103TU, Presario CQ70-103TX, Presario CQ70-104TX, Presario CQ70-105EB, Presario CQ70-105EF, Presario CQ70-105TX, Presario CQ70-110EB, Presario CQ70-110EF, Presario CQ70-110EM, Presario CQ70-110EO, Presario CQ70-110ER, Presario CQ70-110ES, Presario CQ70-111CA, Presario CQ70-115EE, Presario CQ70-115EF, Presario CQ70-115EO.		Category: Laptop
2010/7/8	Delete	CL1848B	Battery	HP	G60-100 Series, G60-200, G60-200, G60-230us, G70-100 Series		Category: Laptop
2010/7/8	Add	CL1032B	Battery	ASUS	Eee PC 1005, Eee PC 1005H, Eee PC 1005HA-E, Eee PC 1005HA-EU1X, Eee PC 1005HA-EU1X-BK, Eee PC 1005HA-PU1X, Eee PC 1005HA-PU1X-BK, Eee PC 1005HA-PU1X-BU, Eee PC 1005HA-V, Eee PC 1005HA-VU1X, Eee PC 1005HA-VU1X-BK, Eee PC 1005HA-VU1X-BU, Eee PC 1005HA-VU1X-PI, Eee PC 1005HA-VU1X-WT, Eee PC 1005P, Eee PC 1005PEG, Eee PC 1101HA-M, Eee PC 1101HA-MU1X, Eee		Category: Laptop
2010/7/8	Add	CL1032B	Battery	ASUS		90-OA001B9100	Category: Laptop
2010/7/12	New	PL290B.053	Battery	SAMSUN			
2010/7/12	New	PL290B.649	Battery	SAMSUN			
2010/7/12	New	ACP290	Charger Plate				
2010/7/12	New	ACP134	Charger Plate				
2010/7/12	New	ACP133	Charger Plate				
2010/7/12	New	AVCP133AZ	Battery	OLYMPUS			
2010/7/12	New	AVCP133EZ	Battery	OLYMPUS			

2010/7/12	New	AVCP133KZ	Battery	OLYMPUS			
2010/7/12	New	AVCP133LZ	Battery	OLYMPUS			
2010/7/12	New	AVCP133A	Battery	OLYMPUS			
2010/7/12	New	AVCP133E	Battery	OLYMPUS			
2010/7/12	New	AVCP133K	Battery	OLYMPUS			
2010/7/12	New	AVCP133L	Battery	OLYMPUS			
2010/7/12	New	ACMPB133A	Battery	OLYMPUS			
2010/7/12	New	ACMPB133E	Battery	OLYMPUS			
2010/7/12	New	ACMPB133H	Battery	OLYMPUS			
2010/7/12	New	ACMPB133L	Battery	OLYMPUS			
2010/7/12	New	ACMPB133Z	Battery	OLYMPUS			
2010/7/12	New	CL3280B.080	Battery	DELL			
2010/7/12	New	CL3280B.082	Battery	DELL			
2010/7/12	New	CL3280B.083	Battery	DELL			
2010/7/12	New	CL3280B.085	Battery	DELL			
2010/7/12	New	CL3280B.086	Battery	DELL			
2010/7/12	New	CL3280B.087	Battery	DELL			
2010/7/12	New	ACMPB134A	Battery	PANASON			
2010/7/12	New	ACMPB134E	Battery	PANASON			
2010/7/12	New	ACMPB134H	Battery	PANASON			
2010/7/12	New	ACMPB134L	Battery	PANASON			
2010/7/12	New	ACMPB134Z	Battery	PANASON			
2010/7/12	New	AVCP134AZ	Battery	PANASON			
2010/7/12	New	AVCP134EZ	Battery	PANASON			
2010/7/12	New	AVCP134KZ	Battery	PANASON			
2010/7/12	New	AVCP134LZ	Battery	PANASON			
2010/7/12	New	AVCP134A	Battery	PANASON			
2010/7/12	New	AVCP134E	Battery	PANASON			
2010/7/12	New	AVCP134K	Battery	PANASON			
2010/7/12	New	AVCP134L	Battery	PANASON			
2010/7/12	New	ACP351	Charger Plate				
2010/7/12	New	AVP351	Charger Plate				
2010/7/12	New	AVS351	Charger Plate				
2010/7/12	New	ACMPB351A	Battery	SONY			
2010/7/12	New	ACMPB351E	Battery	SONY			
2010/7/12	New	ACMPB351H	Battery	SONY			
2010/7/12	New	ACMPB351L	Battery	SONY			
2010/7/12	New	ACMPB351Z	Battery	SONY			
2010/7/12	New	AVCP351AZ	Battery	SONY			
2010/7/12	New	AVCP351EZ	Battery	SONY			
2010/7/12	New	AVCP351KZ	Battery	SONY			
2010/7/12	New	AVCP351LZ	Battery	SONY			
2010/7/12	New	AVCP351A	Battery	SONY			
2010/7/12	New	AVCP351E	Battery	SONY			
2010/7/12	New	AVCP351K	Battery	SONY			

2010/7/12	New	AVCP351L	Battery	SONY		
2010/7/12	New	AVNS351E	Battery	SONY		
2010/7/12	New	AVNS351K	Battery	SONY		
2010/7/12	New	AVNS351SA	Battery	SONY		
2010/7/12	New	AVNS351SE	Battery	SONY		
2010/7/12	New	AVNS351SK	Battery	SONY		
2010/7/12	New	AVNS351SU	Battery	SONY		
2010/7/12	New	AVNS351U	Battery	SONY		
2010/7/12	New	AVMP351A	Battery	SONY		
2010/7/12	New	AVMP351AZ	Battery	SONY		
2010/7/12	New	AVMP351E	Battery	SONY		
2010/7/12	New	AVMP351EZ	Battery	SONY		
2010/7/12	New	AVMP351K	Battery	SONY		
2010/7/12	New	AVMP351SJ	Battery	SONY		
2010/7/12	New	AVMP351SJZ	Battery	SONY		
2010/7/12	New	AVMP351KZ	Battery	SONY		
2010/7/12	New	AVMP351P	Battery	SONY		
2010/7/12	New	AVMP351SA	Battery	SONY		
2010/7/12	New	AVMP351SAZ	Battery	SONY		
2010/7/12	New	AVMP351SE	Battery	SONY		
2010/7/12	New	AVMP351SEZ	Battery	SONY		
2010/7/12	New	AVMP351SK	Battery	SONY		
2010/7/12	New	AVMP351SKZ	Battery	SONY		
2010/7/12	New	AVMP351SU	Battery	SONY		
2010/7/12	New	AVMP351SUZ	Battery	SONY		
2010/7/12	New	AVMP351U	Battery	SONY		
2010/7/12	New	AVMP351UZ	Battery	SONY		
2010/7/12	New	CL3279B.080	Battery	DELL		
2010/7/12	New	CL3279B.082	Battery	DELL		
2010/7/12	New	CL3279B.083	Battery	DELL		
2010/7/12	New	CL3279B.085	Battery	DELL		
2010/7/12	New	CL3279B.086	Battery	DELL		
2010/7/12	New	CL3279B.087	Battery	DELL		
2010/7/12	New	CL7409B.383	Battery	LENOVO		
2010/7/12	New	CL7409B.384	Battery	LENOVO		
2010/7/12	Add	C13	Connector Tips	TOSHIBA	Portege M300, Portege M400, Portege M500, Portege M700, Portege M750, Portege R300, Satellite 5105, Satellite 5200, Satellite 5205, Satellite Pro S300, Satellite U200, Tecra R10, Tecra R10-S4401	Category: Laptop Related Products: AC080.011C13, DC091.005C13, AC080.011, DC120.002C13, DC090.005C13,
2010/7/12	Amend	CL1012B.086	Battery			Size: -> 205.90 X 47.70 X 21.11 mm
						Category: Laptop

2010/7/12	Add	C24	Connector Tips	HP	ProBook 4321S	Related Products: AC090.008C24, AC120.009C24, AC150.010C24, DC091.006C24, DC120.003C24, DC090.006C24, AC090X.008, AC120X.009, AC150X.010, EL1901, EL1692
2010/7/12	Add	PL600D	Battery	SONY	DCR-SX44, DCR-SX83, HDR-CX115E, HDR-CX116E, HDR-CX155E, HDR-CX300	Category: Camcorder Related Products: AVMP55, AVNS55, AVCP55, ACMPB55
2010/7/12	Add	PL601D	Battery	SONY	DCR-SX44, HDR-CX115E, HDR-CX116E, HDR-CX155E, HDR-CX300	Category: Camcorder Related Products: AVMP55, ACMPB55, AVCP55, AVNS55
2010/7/12	Add	PL602D	Battery	SONY	DCR-SR68/R, DCR-SR88, DCR-SX44, DCR-SX63, DCR-SX83, HDR-CX115E, HDR-CX116E, HDR-CX155E, HDR-CX300	Category: Camcorder Related Products: AVMP55, ACMPB55, AVCP55, AVNS55
2010/7/12	Add	PL65D, PL66D, PL67D, PL68D, PL69D	Battery	SONY	DCR-SX83, HDR-CX300	Category: Camcorder Related Products: ACMPB55, AVMP55, AVNS55, AVCP55
2010/7/12	Add	PL306M	Battery	JVC	GR-DVX35K	Category: Camcorder Related Products: AVNS306, AVMP306
2010/7/12	Add	PL312M	Battery	JVC	GR-DVX35K, GR-DVX505K, GR-DVX707K	Category: Camcorder Related Products: AVNS306, AVMP306
2010/7/12	Add	PL316M	Battery	JVC	GR-DVX35K, GR-DVX505K, GR-DVX707K	Category: Camcorder Related Products: AVNS306, AVMP306
2010/7/12	Add	PL308M	Battery	JVC	GR-DVX35K, GR-DVX505K, GR-DVX707K	Category: Camcorder Related Products: AVNS306, AVMP306
2010/7/12	Add	PL306M	Battery	JVC	GR-DVX505K, GR-DVX707K	Category: Camcorder Related Products: AVNS306, AVMP306
2010/7/12	Add	PL514D	Battery	JVC	GR-DVX33K, GR-DVX33K-X	Category: Camcorder Related Products: AVMP507, AVNS507
2010/7/12	Add	PL507D	Battery	JVC	GR-DVX33K, GR-DVX33K-X	Category: Camcorder Related Products: AVNS507, AVMP507
2010/7/12	Add	PL507S	Battery	JVC	GR-DVX33K, GR-DVX33K-X	Category: Camcorder
2010/7/12	Add	PL514S	Battery	JVC	GR-DVX33K, GR-DVX33K-X	Category: Camcorder
2010/7/12	Add	PL207C	Battery	JVC	GR-DVA1, GR-DVF1	Category: Camcorder Related Products: AVMP207
2010/7/12	Add	PL207D	Battery	JVC	GR-DVA1, GR-DVF1	Category: Camcorder Related Products: AVNS207, AVMP207
2010/7/12	Add	PL214C	Battery	JVC	GR-DVA1, GR-DVF1	Category: Camcorder
2010/7/12	Add	PL214D	Battery	JVC	GR-DVA1, GR-DVF1	Category: Camcorder Related Products: AVMP207, AVNS207
2010/7/12	Add	PL408C	Battery	JVC	GR-D500, GR-D61, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder

2010/7/12	Add	PL408D	Battery	JVC	GR-D500, GR-D61, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder Related Products: AVNS408, AVMP408
2010/7/12	Add	PL416C	Battery	JVC	GR-D500, GR-D61, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder
2010/7/12	Add	PL416D	Battery	JVC	GR-D500, GR-D61, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder Related Products: AVNS408, AVMP408
2010/7/12	Add	PL428C	Battery	JVC	GR-D500, GR-D61, GR-D63, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder
2010/7/12	Add	PL428D	Battery	JVC	GR-D500, GR-D61, GR-D65, GR-DV550K, GR-DVA23K, GR-DVF10, GR-DVF11K, GR-DVF202K, GR-DVF20K, GR-DVF303K, GR-DVF305K	Category: Camcorder Related Products: AVNS408, AVMP408
2010/7/12	Add	PL107S	Battery	JVC	GR-DVP1T, GR-DX103K, GR-DX115, GR-DX117, GR-DX73K, GR-DX85	Category: Camcorder
2010/7/12	Add	PL115S	Battery	JVC	GR-DVP1T, GR-DX103K, GR-DX115, GR-DX117, GR-DX73K, GR-DX85	Category: Camcorder
2010/7/12	Add	PL707D	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL707S	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL714D	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL714S	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL733D	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL733S	Battery	JVC	GR-D293, GR-D390, GR-D393, GR-DF577 GR-D351	Category: Camcorder Related Products: AVNS707, AVMP707
2010/7/12	Add	PL808D	Battery	JVC	GZ-HD230, GZ-HD260, GZ-HM110, GZ-HM80, GZ-HM90, GZ-MG120, GZ-MG140, GZ-MG210, GZ-MG211, GZ-MG220, GZ-MG250, GZ-MG260, GZ-MG261, GZ-MG262, GZ-MG35, GZ-MG36, GZ-MG650,	Category: Camcorder Related Products: ACMPB808, AVNS808, AVMP808, AVCP808
2010/7/12	Add	PL818D	Battery	JVC	GZ-HD230, GZ-HD260, GZ-HM110, GZ-HM80, GZ-HM90, GZ-MG120, GZ-MG140, GZ-MG210, GZ-MG211, GZ-MG220, GZ-	Category: Camcorder

					MG250, GZ-MG260, GZ-MG261, GZ-MG262, GZ-MG35, GZ-MG36, GZ-MG650,	Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/12	Add	PL828D	Battery	JVC	GZ-HD230, GZ-HD260, GZ-HM110, GZ-HM80, GZ-HM90, GZ-MG120, GZ-MG140, GZ-MG210, GZ-MG211, GZ-MG220, GZ-MG250, GZ-MG260, GZ-MG261, GZ-MG262, GZ-MG35, GZ-MG36, GZ-MG650,	Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808
2010/7/12	Add	PL808D	Battery	JVC	GR-D751, GR-D790, GR-D793, GR-D851, GR-D853, GZ-HD300AEK, GZ-HD300AUS, GZ-HD300BEK, GZ-HD300BUS, GZ-HD300REK, GZ-HD300RUS, GZ-HD320BUS, GZ-HM1, GZ-HM1S, GZ-HM1SEK, GZ-HM1SEU, GZ-HM1SUS, GZ-HM200BEK, GZ-HM400EU, GZ-HM400U, GZ-MG150US, GZ-MG255US, GZ-MG330AUS, GZ-MG330HUS, GZ-MG330RUS, GZ-MG335HUS, GZ-MG335WUS, GZ-MG340BUS, GZ-MG360BUC, GZ-MG360BUS, GZ-MG365BUS, GZ-MG430HUS, GZ-MG435HUS, GZ-MG465BUS, GZ-MG610SEU, GZ-MG630AEK, GZ-MG630AUS, GZ-MG630REK, GZ-MG630RUS, GZ-MG630SEK, GZ-	Category: Camcorder Related Products: ACMPB808, AVNS808, AVMP808, AVCP808
2010/7/12	Add	PL818D	Battery	JVC	GR-D751, GR-D790, GR-D793, GR-D851, GR-D853, GZ-HD300AEK, GZ-HD300AUS, GZ-HD300BEK, GZ-HD300BUS, GZ-HD300REK, GZ-HD300RUS, GZ-HD320BUS, GZ-HM1, GZ-HM1S, GZ-HM1SEK, GZ-HM1SEU, GZ-HM1SUS, GZ-HM200BEK, GZ-HM400EU, GZ-HM400U, GZ-MG150US, GZ-MG255US, GZ-MG330AUS, GZ-MG330HUS, GZ-MG330RUS, GZ-MG335HUS, GZ-MG335WUS, GZ-MG340BUS, GZ-MG360BUC, GZ-MG360BUS, GZ-MG365BUS, GZ-MG430HUS, GZ-MG435HUS, GZ-MG465BUS, GZ-MG610SEU, GZ-MG630AEK, GZ-MG630AUS, GZ-MG630REK, GZ-MG630RUS, GZ-MG630SEK, GZ-	Category: Camcorder Related Products: ACMPB808, AVNS808, AVCP808, AVMP808

2010/7/12	Add	PL828D	Battery	JVC	<p>GR-D751, GR-D790, GR-D793, GR-D851, GR-D853, GZ-HD300AEK, GZ-HD300AUS, GZ-HD300BEK, GZ-HD300BUS, GZ-HD300REK, GZ-HD300RUS, GZ-HD320BUS, GZ-HM1, GZ-HM1S, GZ-HM1SEK, GZ-HM1SEU, GZ-HM1SUS, GZ-HM200BEK, GZ-HM400EU, GZ-HM400U, GZ-MG150US, GZ-MG255US, GZ-MG330AUS, GZ-MG330HUS, GZ-MG330RUS, GZ-MG335HUS, GZ-MG335WUS, GZ-MG340BUS, GZ-MG360BUC, GZ-MG360BUS, GZ-MG365BUS, GZ-MG430HUS, GZ-MG435HUS, GZ-MG465BUS, GZ-MG610SEU, GZ-MG630AEK, GZ-MG630AUS, GZ-MG630REK, GZ-MG630RUS, GZ-MG630SEK, GZ-</p>	<p>Category: Camcorder</p> <p>Related Products: ACMPB808, AVNS808, AVCP808, AVMP808</p>
-----------	-----	--------	---------	-----	--	---