

Date	Process	PP Code	Type	Brand	Fit Model	Replace Code	Others
2010-5-24	Delete	BL3600B	Battery	MOTOROLA	V66, V66		Category: Mobile Phone
2010-5-24	New Product	CL1186S.080	Battery	LENOVO			
2010-5-24	New Product	CL1186S.082	Battery	LENOVO			
2010-5-24	New Product	CL1186S.083	Battery	LENOVO			
2010-5-24	New Product	CL1186S.085	Battery	LENOVO			
2010-5-24	New Product	CL1186S.086	Battery	LENOVO			
2010-5-24	New Product	CL1186S.087	Battery	LENOVO			
2010-5-24	New Product	CL5114B.080	Battery	SONY			
2010-5-24	New Product	CL5114B.082	Battery	SONY			
2010-5-24	New Product	CL5114B.083	Battery	SONY			
2010-5-24	New Product	CL5114B.085	Battery	SONY			
2010-5-24	New Product	CL5114B.086	Battery	SONY			
2010-5-24	New Product	CL5114B.087	Battery	SONY			
2010-5-24	New Product	CL5115B.080	Battery	SONY			
2010-5-24	New Product	CL5115B.082	Battery	SONY			
2010-5-24	New Product	CL5115B.083	Battery	SONY			
2010-5-24	New Product	CL5115B.085	Battery	SONY			
2010-5-24	New Product	CL5115B.086	Battery	SONY			
2010-5-24	New Product	CL5115B.087	Battery	SONY			
2010-5-24	New Product	CL5135S.15P	Battery	SONY			
2010-5-24	New Product	PL211B.635	Battery	CASIO			
2010-5-24	Amend	PLW139B	Battery				Remark: -> Not compatible with Lumix DMC-G2.
2010-5-24	New Product	PL826B.855	Battery	CANON			
2010-5-24	New Product	PL826B.853	Battery	CANON			
2010-5-24	New Product	CL2677B.087	Battery	HP COMPAQ			

Date	Process	PP Code	Type	Brand	Fit Model	Replace Code	Others
2010-5-24	New Product	CL2800A.083	Battery	COMPAQ, ASUS			
2010-5-24	Add	PLW154B	Battery	PANASONIC		DMW-BCG10PP	Category: Digital Camera Related Products: AVEP154, AVMP154, AVCP154, ACMPB154, AVNS154
2010-5-24	Delete	CL7330B	Battery	LENOVO	IdeaPad Y330, IdeaPad Y330A, IdeaPad Y330G		Category: Laptop
2010-5-24	Delete	CL7330B	Battery	LENOVO		L08L6D11, L08S6D11	Category: Laptop
2010-5-24	Add	CL8529B	Battery	PANASONIC	CF-52MW1ADS, CF-52MW1APS		Category: Laptop
2010-5-24	Add	CL8649S	Battery	PANASONIC	CF-R9KWDCDS		Category: Laptop
2010-5-24	Add	CL655B	Battery	FUJITSU	LifeBook T730, LifeBook T730TRNS		Category: Laptop
2010-5-24	Add	CL655B	Battery	FUJITSU		S26391-F795-L600	Category: Laptop
2010-5-24	Add	CL7400B	Battery	ACER	Aspire 1410(old version)		Category: Laptop
2010-5-24	Delete	CL7400B	Battery	ACER	Aspire 1410, Aspire 1410		Category: Laptop
2010-5-24	Add	CL6176B	Battery	FUJITSU	LifeBook A6210, LifeBook AH550, LifeBook E8420E		Category: Laptop
2010-5-24	Add	CL6462B	Battery	FUJITSU	LifeBook A1220, LifeBook AH550, LifeBook E8410		Category: Laptop
2010-5-24	Add	CL6462B	Battery	FUJITSU		CP335311-01, FPCBP175, FPCBP234, FPCBP234AP	Category: Laptop
2010-5-27	Add	PL357B	Battery	SAMSUNG	TL210		Category: Digital Camera Related Products: AVNS357, AVMP357, AVEP357, AVCP357, ACMPB357
2010-5-27	Add	PL357B	Battery	SAMSUNG		SLB-07B	Category: Digital Camera Related Products: AVNS357, AVMP357, AVEP357, AVCP357, ACMPB357